



SHO1 SHO1-2

Hybridization Oven

Installation, Operation, and
Maintenance Guide

Previously Designated
As Models 1013 1013-2

Sheldon Manufacturing Inc. P.O. Box 627 Cornelius, Oregon 97113
EMAIL: tech@Shellab.com **INTERNET:** <http://www.Shellab.com/~Shellab>
1-800-322-4897 (503) 640-3000 FAX (503) 640-1366
4861629
01-07

Safety Notices

CAUTION

A **CAUTION** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in damage to the product or loss of important data. Do not proceed beyond a **CAUTION** notice until the indicated conditions are fully understood and met.

WARNING

A **WARNING** notice denotes a hazard. It calls attention to an operating procedure, practice, or the like that, if not correctly performed or adhered to, could result in personal injury or death. Do not proceed beyond a **WARNING** notice until the indicated conditions are fully understood and met.

TABLE OF CONTENTS

Safety and Regulatory Information	4
Technical and Environmental Specifications.....	5
Symbols.....	5
Fuses and Battery	5
Cleaning	5
Recycling the Product	5
Installation	6
Prepare the Site	6
Power source	6
Environment.....	6
Location	6
Inspect the Shipment.....	7
Inspection	7
Ship kit contents.....	7
Return shipment process	8
Unpack and Place the Oven	8
Install the Oven	8
Install the leveling feet.....	8
Install the drip tray	8
Install the rotator	9
Clean the oven.....	9
Install the power cord.....	9
Operation	10
Control Panel Interface	10
Operating the Hybridization Oven.....	11
To set a temperature.....	11
To load or unload the hybridization chamber	11
To calibrate the oven.....	12
Maintenance and Troubleshooting	13
Cleaning	13
Storage	13
Electrical components	13
Replacing the inline power fuse.....	14
Troubleshooting	15
Unit Specifications	17
Net weight.....	17
Interior dimensions	17
Temperature	17
Rotation Speed	17
Wiring Diagram	18

Safety and Regulatory Information

Intended Use

This unit is for professional, industrial, or educational use, where the preparation or testing of materials is done at approximately atmospheric pressure and no flammable, volatile, or combustible materials are being heated. This unit is not intended for hazardous or household use.

Important Safety Warnings

There are several important safety notices that you should always keep in mind when using the Hybridization Oven.

Many internal parts of the instrument carry dangerous voltages

If the oven is connected to a power source, even if the power switch is off, potentially dangerous voltages exist on: • the wiring between the oven power cord and the AC power supply • the AC power supply itself • the wiring from the AC power supply to the power switch With the power switch on, potentially dangerous voltages also exist on: • all electronics boards in the oven • the internal wires and cables connected to these boards

WARNING

All these parts are shielded by covers. With the covers in place, it should be difficult to accidentally make contact with dangerous voltages. Unless specifically instructed to, never remove a cover.

WARNING

If the power cord insulation is frayed or worn, the cord must be replaced. Contact your customer service representative.

Technical and Environmental Specifications

Below are the oven's technical and environmental specifications.

- Class 1 equipment
- Pollution degree 2
- Installation Category II
- Indoor use only in ordinary atmospheres
- Operating ambient temperatures between 15 °C and 35 °C
- Relative humidity between 15 % to 85 %
- Altitude not to exceed 2000 m operating
- G2545A is rated for mains connection to 100–120 VAC or 220–240 VAC, 50/60 Hz, 6A, with main supply voltage fluctuations up to $\pm 10\%$ of the nominal voltage

Symbols

Warnings in the manual or on the oven must be observed during all phases of operation, service, and repair of this oven. Failure to comply with these precautions violates safety standards of design and the intended use of the oven. Sheldon Manufacturing, Inc. assumes no liability for the customer's failure to comply with these requirements.



See accompanying instructions for further description or discussion of a control or user item.



Indicates a hot surface.



Indicates earth (ground) terminal.



Indicates potential shock hazard behind this partition.

Fuses and Battery

The oven uses one 5 × 20 mm fuse, 6.3 A, 250 V, type T. This fuse is located at the rear of the oven, above the power cord receptacle.

Cleaning

See "Cleaning" on page 14.

Recycling the Product

For recycling, contact your local sales office.

Installation

Prepare the Site

Local city, county or other ordinances may govern the use of this equipment. If you have any questions about local requirements, please contact the appropriate local agency. The end user may perform installation, as it is unnecessary for this unit to be installed by a technician.

Power source

The electrical supply circuit to the oven must conform to all national and local electrical codes. Consult the oven's serial data plate (located on the top back panel of the oven) for the voltage, cycle wattage, and ampere requirements before connecting to power. A separate circuit is recommended to prevent possible loss of product due to overloading or failure of other equipment on the same circuit. The supply voltage should not vary by more than 10%.

Environment

Under normal circumstances, this unit is intended for use indoors at room temperatures between 15 °C and 35 °C, and relative humidity between 15%–85%. Contact Customer Service if operating in conditions outside of these limits.

Location

In selecting a location, consider all conditions that might affect performance, such as heat from radiators, ovens, autoclaves, etc. Avoid direct sun, fast moving air currents, heating/cooling ducts, and high-traffic areas. Allow a minimum of 5 cm (2.0 in) between the unit and walls or partitions, as they may obstruct free air flow.

NOTE

Please read this manual before attempting to install the oven.

Inspect the Shipment

Your satisfaction and safety require a complete understanding of this unit. Read the instructions thoroughly and be sure all operators are given adequate training before attempting to put the unit in service.

Inspection

The carrier, when accepting shipment, also accepts responsibility for safe delivery and is liable for loss or damage. On delivery, inspect for visible exterior damage, note and describe on the freight bill any damage found, and enter your claim on the form supplied by the carrier. Inspect for concealed loss or damage on the unit, both interior and exterior. If necessary, the carrier will arrange for official inspection to substantiate your claim. Verify that all of the equipment indicated on the packing slip is included with the unit. Carefully check all packaging before discarding.

Ship kit contents

Each oven unit comes with the following items that need to be installed (See Figure 1)

- A power cord set (depending on the voltage at the country of origin)
- Drip tray
- Four adjustable feet
- Brass locking pin
- The rotator (it is also called the “rotisserie,” part number 9670511) **is** included with the 1013 model.



Figure 1 Ship kit

NOTE

This equipment must be used only for its intended application; any alterations or modifications will void your warranty.

Return shipment process

Save the shipping crate for future use. The shipping crate will be used to ship the oven back to the factory for repair, if needed. If for any reason you must return the unit, please contact Customer Service Representative for authorization.

Please have the model number and serial number available when calling the Customer Service Representative.

Fill out the Environment Health and Safety (EH&S) form completely and attach it to the oven before shipping.

Unpack and Place the Oven

Before lifting/handling the 1013, note:

- This unit weighs 75.0 lbs. (34.0 kg) and should not be lifted from the ground to the bench by one person.
- Multiple persons or an appropriate lifting device that is sufficiently rated for these loads should be used.
- Units should only be lifted from their bottom surfaces. Doors, handles and knobs are not adequate for lifting or stabilization.
- The unit should be completely restrained from tipping during lifting or transport.
- Loose parts, such as drip trays, should be removed. Doors need to be positively locked in the closed position during transfer to prevent shifting and damage.

Install the Oven

Install the leveling feet

For the 1013 Hybridization Oven to operate properly, the unit must sit level and on a solid foundation. To ensure that the instrument is level:

1. Install the supplied leveling feet in the four holes located in the bottom corners of the unit by screwing them in.
2. Adjust the foot at each corner until the unit stands level and solid without rocking.

Install the drip tray

Install the drip tray on the bottom of the oven. Make sure the oven door can close once the tray is installed.

CAUTION

If the unit must be moved, turn the leveling feet all the way clockwise to prevent damage while moving.

Install the rotator

The rotator (also called rotisserie, Sheldon part number 9670511; see Figure 5) comes with your 1013 oven. To install the rotator into the oven:

1. Set the AC power switch to **OFF**.
2. Open the oven. Locate the rotator drive shaft coupling on the left side oven wall and the rotator shaft support bushing on the right side oven wall. See Figure 2.
3. Move the rotator into the oven and insert the two pins on the rotator drive shaft coupling into the two holes on the rotator coupling. See Figure 3.
4. While holding the rotator to keep the drive coupling attached, lower the rotator shaft into the slot in the rotator shaft support bushing. See Figure 4.
5. Complete rotator installation by inserting the brass locking pin through the two holes in the shaft support bushing. See Figure 5.




Figure 2 Rotator shaft attachment locations



Figure 3 Attaching the rotator to the drive shaft coupling



Figure 4 Inserting the rotator shaft into the rotator shaft support bushing



Holes for brass locking pin

Figure 5 Rotator correctly installed

Clean the oven

Before first use, clean the oven as described in “Cleaning” on page 14.

Install the power cord

The correct power cord that is appropriate for your country will ship with the unit.

WARNING

Use of an inappropriate power cord may damage your oven or pose a safety hazard.

Operation

Control Panel Interface

The 1013 Hybridization Oven is operated using the control panel interface (see Figure 6), which is located on the front of the oven.


Rotational speed control Use to set the rotator speed from 2 to 20 rpm. Turning the knob clockwise increases the rotator speed. Set to 0 (zero) to turn off the rotator.

Heating indicator Lights continuously when the oven is heating. Blinks when the oven is at or near its set point.

Temperature display Displays the current oven temperature in degrees centigrade (°C).

Temperature controls Use the up and down arrow keys to adjust the oven temperature set point.


JOG switch Press and hold **ON** to turn the rotator, for example, when loading the oven. When released, the rotator stops. The rotational speed control knob **cannot** be set at zero for the **JOG** switch to operate properly.



Operating the Hybridization Oven

To set a temperature


Using the temperature controller:

1. Enter set point mode by pressing **either** ▲ or ▼ 
The digital display will start to blink. While blinking, the digital display shows the current **set point**.
2. Press ▲ or ▼ to enter the desired set point temperature.
If the arrow pads are not pressed for five (5) seconds, the display will stop blinking and will read the temperature in the chamber.

To load or unload the hybridization chamber

Load the samples into the oven as follows:

1. Open the oven door. If the rotator is in motion, it will stop moving once the oven door is opened.
2. Use the **JOG** switch to move the rotator to the desired chamber load/unload position. The rotator speed should be at least 2.
3. Load or unload the hybridization chambers. To load the bottles into the rotator, press the bottles into the upper and lower clips until locked in place. See picture below.
4. Use the **JOG** switch to move the rotator to the next rack, and continue loading/unloading the bottles. After loading/unloading all bottles, close the oven door.



NOTE

For stable control, the set point must be a minimum of 5 degrees above ambient.

WARNING

The oven and rotator may be hot. Before handling, lower the oven temperature to <35 °C and allow it to cool, or wear heat-resistant gloves.

CAUTION

When loading samples onto the rotator, be sure to balance the load between the racks. Also take care in balancing the loads horizontally on the racks themselves.

To calibrate the oven

Calibrate the oven:

- After first installation in a working environment.
- After each 3 months of use

To calibrate the oven:

1. Install the rotator and load it with a typical number of chambers.
2. Turn on the oven and set to a typical operating temperature.
3. Allow the oven to stabilize for at least 1 hour.
4. Place a certified reference thermometer in the chamber near the sample area.
5. Allow the temperature to stabilize again until the thermometer reads a constant value for one hour.
6. Compare the digital display on the control panel with the reference thermometer.
7. If there is a difference of more than 0.2 °C, put the display into calibration mode by pressing **both ▲ and ▼** at the same time until the temperature display's two outside decimal points begin to flash.
8. While the decimal points are flashing, press the ▲ or ▼ arrow pad until the display reads the correct value.

Allow the oven to stabilize, and then recheck the temperature. Repeat step 5 through step 8, if necessary.

NOTE

Sheldon highly recommends recalibrating the oven temperature every three (3) months. To ensure correctness of temperature calibration, the rotator needs to be installed and loaded.

NOTE

Sheldon recommends using a digital thermometer for calibration.

Maintenance and Troubleshooting

Cleaning

To clean the unit:

1. Remove the rotator and drip tray.
2. Clean the oven using mild detergent.
3. Clean the rotator and drip tray using either the same solution used for the chamber, or an autoclave.

Storage

If the unit is to be turned off for any length of time, **assure that the chamber and drip tray are dry and store at room temperature.** Failure to do this may cause the interior to become contaminated. No adjustment to controls should be required when restarting the unit.

If the unit is shut down for transport, be sure to disconnect the power cord and turn the leveling feet in all the way. See Chapter 2, “Unpack and Place the Oven” for further instruction on preparing the oven for transportation.

Electrical components

There is no maintenance necessary on electrical components. If the unit fails to operate as specified, review “Troubleshooting” on page 16 before calling for service.

WARNING

Prior to any maintenance or service on this unit, disconnect the power cord from the oven. The oven interior surface should be cleaned once a month.

CAUTION

Do not use chlorine-based bleach or abrasives, as this will damage the chamber interior.

Replacing the inline power fuse

The unit is protected by an inline fuse located behind the power cord. If needed, replace the fuse as described below:

1. Turn off the oven and rotator, then disconnect from the power source.
2. Remove the power cord from the back of the oven.
3. Using a small, flat-bladed screwdriver pry the fuse holder from the back of the unit. See Figure 8.
4. Inspect the fuse in service. See Figure 9. Replace if blown with a 6.3 A, 250 V type T fuse.




Figure 8 Removing the fuse holder



Figure 9 Inline fuse and spare

WARNING

If the inline power fuse blows repeatedly, check for the reason why. Check that the oven is the correct voltage type, check the power cord, and check the power supply.

Troubleshooting

The following table shows a list of problems and their corresponding solutions. If these instructions do not correct the problem, call Customer Service for further assistance.

Table 1 Problems and solutions

Problem	Action
The unit will not turn on.	<ol style="list-style-type: none">1 Verify that the power cord is plugged into the oven and power source.2 Verify that the power switch is ON.3 Check the fuse as described in “Replacing the inline power fuse” on page 15 and replace if blown.
Temperature is too high.	<ol style="list-style-type: none">1 The controller might be set too high. To set the oven temperature, see “To set a temperature” on page 12.
Display reads “HI”.	<ol style="list-style-type: none">1 Check if the set temperature is below the room temperature.2 Turn the unit OFF. Wait for five seconds and then turn it on to see if the error message disappears.
Chamber temperature overshoots the set point and then settles to the set point.	For hybridization units, $\pm 1^{\circ}$ of set point may be normal. To recalibrate the oven, see “To calibrate the oven” on page 13.
Temperature is too low.	<ol style="list-style-type: none">1 The controller might be set too low. To set the oven temperature, see “To set a temperature” on page 12 for information on setting the oven temperature.2 The unit may not have recovered from opening the door; wait for the display to stabilize.3 The unit may not have recovered from a power failure or from being turned off. Ovens usually will need two hours to warm up and stabilize.
Display reads “LO”.	The ambient temperature might be below the temperature range of the unit. Refer to “Technical and Environmental Specifications” on page 6.
The unit will not heat over a temperature that is below the set point.	<ol style="list-style-type: none">1 Confirm that the fan is moving. Check fan motor motion and feel for air movement in chamber.2 Confirm that the supply amperage and voltage match the data plate.3 To calibrate the oven, see “To calibrate the oven” on page 13.
The unit will not heat up at all.	Make sure that the circuit breaker and fuse have not blown and are still operating correctly.

Table 1 Problems and solutions (continued)

Problem	Action
The indicated chamber temperature is unstable.	Temperature range ± 1 °C is normal. 1 Check to make sure the fan is working by checking the fan motor motion and feeling for air movement in the chamber. Verify movement of the cooling fan in the back of chamber. 2 Doors opening, air flow from heaters, and air flow from air conditioner units may radically change the ambient room temperature. Stabilize ambient conditions. Assure that the oven set point is at least 5 °C above the ambient room temperature. 3 See if the ambient room temperature is fluctuating. 4 Verify that the unit is not affected by another temperature source, such as direct sunlight or direct air conditioning to the unit.
Display and reference thermometer do not match.	There may be a calibration error. To recalibrate the oven, see "To calibrate the oven" on page 13. Allow two hours for the temperature to stabilize.
The set point or calibration cannot be adjusted.	Turn the entire unit OFF and then ON to reset.
The oven is calibrated at one temperature, but not at another.	This can be a normal condition when the operating temperature varies widely. For maximum accuracy, calibration should be done at or as close as possible to the operating temperature in use.
Black soot might appear on the oven floor and walls.	Clean the interior oven as specified on page 14.

Unit Specifications

Net weight

Unloaded unit weight, without rotator: 75.0 lbs (34.0 kg)

Interior dimensions

12.5 in wide x 12 in deep x 14.5 in high (31.8 cm x 30.5 cm x 36.8 cm)

Temperature

Operating temperature range: Amb. +5 °C to 70 °C

Precision: 0.1 °C

Rotation Speed

20 mph

Wiring Diagram

